


TERRAPIN X


CONNECTING

your TERRAPIN X to the Strelok Pro ballistic app







- By pressing and releasing the push button of your TERRAPIN X you turn on the device
- You will now see the digital aiming reticle in the display of your TERRAPIN X



- Press and release the push button of your TERRAPIN X three times in quick succession to enter the Bluetooth menu
- In the display you will see the last saved setting. This can either be "OFF", "APP", "hEST" (for KESTREL) or "tdH"




- Toggle through the options by pressing and releasing the push button of your TERRAPIN X until you reach "tdH"



- Confirm this setting by pressing and releasing the push button three times in quick succession
- As confirmation four dashes ("----") will appear in the display of your TERRAPIN X
- Besides the electronic aiming reticle you will now also see a flashing Bluetooth symbol in the display of your TERRAPIN X. This signifies that the TERRAPIN X has entered the pairing mode



- Make sure that Bluetooth is enabled in the general settings of your smartphone
- For iOS devices also allow access to Bluetooth in Settings > Privacy > Bluetooth
- Open the Strelok Pro ballistic app on your smartphone and enter the home screen of the app
- In the lower part of the screen click on the TERRAPIN X symbol



- The Strelok Pro app will search for your TERRAPIN X and connect to it

When a connection is established, the TERRAPIN X transmits range, azimuth and elevation to the Strelok Pro ballistic app. Using this data, the Strelok Pro ballistic app calculates an accurate firing solution.

VISIT US ON INSTAGRAM, YOUTUBE OR ON OUR WEBSITE
www.terrapin-x.com #myTPNX

